


# Dispenser Cleaning

## Dispensing Valves – Nightly




Remove all nozzles from dispenser by turning clockwise and pulling down.

Place nozzles and diffusers in a sanitizing solution and scrub each piece individually with a brush. Allow them to soak for 15 minutes.

Remove clean nozzles and diffusers from the solution.

Thoroughly rinse with warm water and let dry on a clean towel.

## Drip Pan – Nightly




Remove cup rest. Wash, rinse and sanitize.

Pour 1 quart warm water throughout pan and down drip pan drain.

Wipe inside walls of drip pan with a towel dipped in sanitizer solution.

Replace cup rest.

## Dispenser – Nightly




Using a towel dipped in sanitizer solution, wipe:

Backsplash and sides.

Underneath dispenser valves (where nozzles and diffusers connect to valves)

## Ice Cooled Unit – Weekly



Wipe down inside walls and surface of cold plates with warm water and a soft, clean cloth.

Rinse completely with warm water.